




TOP AND CABINET PARTS

FOR MODELS: LSR6233BW1, LSR6233BN1

(WHITE)

(ALMOND)

AUTOMATIC
WASHER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS

FOR MODELS: LSR6233BW1, LSR6233BN1

(WHITE) (ALMOND)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	357213	Nut, Push-In (2)	6	62780	Clip, Top & Cabinet & Rear Panel (2)	19		Lid
2	3358200	For White Model	8	3356311	Screw & Washer, Lid Switch (2)		3361392	For White Model
	3358201	For Almond Model	11	3352629	Switch, Lid	20	3361393	For Almond Model
3	62750	Spacer, Cabinet To Top (4)	13	3351355	Screw, Lid Hinge Mounting (4)	22	358684	Strike, Lid Switch
5		Cabinet	15	54584	Hinge, Lid (L.H.)	28	93770	Bumper, Lid (2)
	63424	For White Model	16	54583	Hinge, Lid (R.H.)		384435	Screw, 10-16 x 1/2 (5)
	63425	For Almond Model	17	19119	Bumper, Lid Hinge	31	90016	Clip, Harness
			18	21258	Bearing, Lid Hinge (2)	32	3362952	Dispenser, Bleach

LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<u>LITERATURE PARTS</u>			<u>OPTIONAL PARTS NOT INCLUDED</u>					
	LIT3360057	Sheet, Installation Instructions	<u>PAINT, TOUCH-UP (1/2oz.)</u>			<u>LUBRICANT</u>		
	LIT3357460	Guide, Use and Care		72017	White		285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)
	LIT3361377	Energy Guide		72107	Almond	<u>SEALER</u>		
	LIT3946992	Label, Wiring Diagram		72110	Golden Harvest		285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
<u>Following May Be Purchased</u>			<u>PAINT, PRESSURIZED SPRAY (13 oz.)</u>			<u>SHIPPING KIT</u>		
<u>DO-IT-YOURSELF REPAIR MANUALS</u>				350938	Primer, Gray		3348675	Shipping Kit
	LIT4313896	Manual, (Washer) Do-It-Yourself		350930	White	<u>ACCESSORY PARTS</u>		
				350956	Almond		89121	Stand-Pipe Kit
				261890	Golden Harvest		367031	Drain Protector
			<u>PAINT, BULK (1 qt.)</u>				285320	Siphon Break Kit
				799344	White (Uncut)			
				978883	Almond (Uncut)			
				261891	Golden Harvest (Uncut)			
			<u>OIL</u>					
				350572	Oil, Gearcase (16 Oz.)			


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROLS AND REAR PANEL PARTS

FOR MODELS: LSR6233BW1, LSR6233BN1

(WHITE)

(ALMOND)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


CONTROLS AND REAR PANEL PARTS

FOR MODELS: LSR6233BW1, LSR6233BN1

(WHITE) (ALMOND)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	16123	Washer, Water Inlet Hose (4) (1-1/16 x 5/8)	16		Cap, End (L.H.)	35	661538	Switch, Water Temperature
3	3354858	Hose, Water Inlet (2)		3358531	White/Chrome			3347117 (Alt.)
4	3357027	Nozzle, Drain Hose	17	96160	Screen, Filter (2)			3348352 (Alt.)
5	387402	Hinge, Console (2)	18	3360392	Valve, Water Mixing	36	96435	Screw, Timer Mounting
6	3357978	Panel, Rear	19	90864	Screw, 10-24 x 3/8 (2)			(10-32 x 1) (2)
7	62747	Pad, Rear Panel	21	370451	Clamp, Hose 272846 (Alt.)	39		Panel, Console
8	661575	Hose, Drain (4'- 8")			353367 (Alt.)		3361504	For White Model
	661577	Hose, Drain (9'- 9") (Not Included)	22	3357328	Hose, Vacuum Break	44	3361505	For Almond Model
	3357090	Extension, Drain Hose (21 Inches.) (Not Included.)	23	371503	Clamp, Hose	45	3364290	Knob, Timer
9	3946439	Timer, Control (60 Hz.) (Motor Not A Service Part)	24	387606	Break, Vacuum	47	3946260	Dial, Timer
11	90767	Screw 8A x 3/8	25	63290	Support, Rear Panel	49	3358431	Knob, Control
12	3356467	Switch, Water Level	26	3361805	Hose-Corrugated Assy.	50	3353145	Screw, 8-18 (2) (Panel to Top)
13	3360936	Bracket, Control	27	356138	Clamp, Hose	51	62863	Screw, 10-16 x 3/8
14	3360514	Cord, Power	30	371502	Clamp, Hose			Cap , End (R.H.)
15	63848	Strain Relief, Power Cord	31	660628	Clamp, Hose 272858 (Alt.)		3358516	White/Chrome
					370447 (Alt.)		3358517	Almond/Chrome
			32	62731	Hose, Pump To Tub	55	3357011	Screw, 10-16 x 1/2
						58	3357331	Clamp, Drain Hose
						59	3348424	Shield, Suds
						60	3359831	Harness, Wiring (For Detail See Page 7.) Also See Clips.

MISCELLANEOUS PARTS



Illus. No.	Part No.	DESCRIPTION
1	3359460	Miscellaneous Parts Bag
2	16123	Washer, Inlet Hose (1-1/16 x 5/8) (4)
4	3359452	Nut, Lock (3/8-16)
5	389102	Foot, Front (2)
7	356138	Clamp, Hose

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

(WHITE) (ALMOND)



AGITATOR, BASKET AND TUB PARTS

FOR MODELS: LSR6233BW1, LSR6233BN1

(WHITE) (ALMOND)


Illus. No.	Part No.	DESCRIPTION
1	3355758	Cap, Agitator
2	358237	Screw & Washer (5-16-24 x 1)
3	3348752	Clothes Mover
4	3347288	Agitator
5	63851	Tub Ring & Gasket
6	3359585	Gasket, Tub Ring
9	3351001	Cam Driven
10	387091	Dog, Agitator Clutch
12	21366	Nut, Spanner
13	64217	Basket & Balance Ring
14	3361948	Filter, Plate
16	388893	Tub
17	389140	Block, Basket Drive
18	383727	Gasket, Centerpost
19	3347780	Hose, Pressure Switch
20	3348117	Agitator (Complete Asy.)
22	3350389	Spacer, Thrust
23	3347290	Cap, Barrier
24	3348855	Seal, Inner Cap
25	3358198	Hose, Bleach

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

FOR MODELS: LSR6233BW1, LSR6233BN1

(WHITE) (ALMOND)



WH2D

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3349557	Clip, Harness	11	353424	Plug, Terminal (3-Way) (Power Cord) (Use Term.94613)	19	3390423	Block, Disconnect (12-Way) (Timer) (Use Term. 94613)
2	388498	Clip, Harness	12	62505	Block, Disconnect (Motor 2 Speed) (Use Term.352088)	20	3347730	Receptacle (6-Way) (Use Term. 94613)
3	3347812	Clip, Harness	13	3348075	Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614.)	21	388818	Plug, Terminal (12-Way) (Use Term. 94613 Or 94614.)
4	3352501	Clip, Harness	14	3347243	Block, Disconnect (Use Term. 352088)	22	3369366	Timer, Block Disconnect (Black) (Amp) (Use Term.3369365)
5	90016	Clip, Harness	15	63523	Protector	23	3349494	Connector, Etc
6	3390496	Clip, Harness	16	717252	Connector (2-Way) (Use Term.94614)	24	60687	Connector, Relay (Use Term.308569 Or 338664.)
7	389379	Retainer, (Suds Models)	17	387566	Plug, Terminal (4-Way) (Power Cord) (Use M3 Screws)	25	3407125	E.T.C. Control
8	352090	Timer, Block Disconnect (White)	18	3352944	Clip, Harness			
9	352089	Timer, Block Disconnect (Black)						
10	62889	Receptacle, Terminal (3-Way) (Lid Switch) (Use Term.94613) Or 94614.)						


FOR COMPLETE WIRING HARNESS REFER TO
CONTROL AND REAR PANEL PARTS PAGE

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

FOR MODELS: LSR6233BW1, LSR6233BN1

(WHITE) (ALMOND)




Illus. No.	Part No.	DESCRIPTION
1	343641	Screw, Bracket Mounting (10-16 x 5/8)
2	64067	Bracket, Spring Outer (2)
3	63907	Spring Suspension,(3)
4	3362087	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
6	3348727	Link, Leveling Mechanism (2)
7	62597	Spring, Leveling Mechanism
8	62837	Pin, Knurled
9	62596	Foot, Rear (2)
13	3347047	Bearing, Centerpost (2)
14	357409	Seal, Centerpost (3)
15	388492	Spring, Counterweight
16	62568	Pad, Plate
17	3946509	Plate, Suspension (Includes Illus. 16)
18	3363660	Pad, Base
19	3946512	Base Assembly (Includes Illus. 6, 7, 8, 9, 18 & 26)
21	3359452	Nut, Lock (3/8-16) (2)
22	389102	Foot, Front (2)
23	356934	Seal, Centerpost (2)
24	285203	Centerpost Bearing Kit (Includes Illus. 13, 14 & 23)
25	63134	Ring, Sound Deadening
26	63806	Retainer, Suspension Spring

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS


FOR MODELS: LSR6233BW1, LSR6233BN1

(WHITE) (ALMOND)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake & Drive Tube (Complete) (Refer to Page 10 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3946794	Clutch (Complete)
6	3946793	Band & Lining, Clutch (Includes Illus. 7 & 8)
7	62646	Cap, Clutch Spring (2)
8	3363337	Spring, Clutch
9	3360630	Gearcase (Complete) (Refer To Page 11 For Further Breakdown)
10	3357334	Screw, Gearcase To Base (3)

Illus. No.	Part No.	DESCRIPTION
11	62611	Plate, Motor Mount To Gearcase
12	62691	Grommet, Motor (4)
13	62693	Coupling, Motor & Isolation
15	3355454	Clip, Anti-Rattle
16	3357334	Screw
17	3349637	Retainer, Motor (2)
18	3362089	Shield, Tub To Motor
19	661600	Motor, Main Drive
20	62850	Switch, Main Drive Motor
21	62700	Retainer, Pump (2)
22	3363394	Pump (Complete)
23	3387485	Screw, 10-16 x 5/8
24	3946532	Shield, Motor
25	62863	Screw, 10-16 x 3/8
26	357021	Capacitor
27	357030	Clamp, Capacitor



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

(WHITE) (ALMOND)




285208 Lubricant
(Use Only In
Brake Shoe
Assembly On
Roller & Pin)

881178

GEARCASE PARTS

FOR MODELS: LSR6233BW1, LSR6233BN1
(WHITE) (ALMOND)




Illus. No.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	62685	Cover, Gearcase
3	62787	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389243	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring (2)
10	62676	Spring, Agitate
11	62533	Gear, Agitate
12	62619	Washer, Agitate Gear
13	62580	Cam Follower
14	62581	Cam, Agitate
15	389240	Shaft, Agitator
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389229	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
22	90864	Screw, Gearcase Cover Mounting (8) (10-24 x 3/8)
23	95082	Ring, Retaining
24	285292	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	62534	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

GC-215A

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WATER SYSTEM PARTS

FOR MODELS: LSR6233BW1, LSR6233BN1
(WHITE) (ALMOND)



WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector (Not Included)